

Download To USB Instruction (Xion)

1. Insert memory stick into USB port on the front of the DVR.
2. Use the mouse to slide the cursor to the bottom of the screen until the icon box appears.
3. Left click on the left hand icon marked TOOL.
4. Move the cursor and click on the option BACKUP.
5. Left click in the numbered boxes to indicate which cameras you want to download from.
6. Left click on the FROM time and date box. Next left click on the day you want to record from on the calendar.
7. Under the calendar is the time, left click the up and down arrows at the side of the time to adjust, this is the start time.
8. Left click the OK.
9. Now left click the TO time and date box and change the end **date** and **time** the same as before.
10. Left click the SCAN box, the DVR will record the name of the memory stick in the box marked DEVICE.
11. If you need to check the size of the download left click the ESTIMATE box and it will display the file size to be downloaded.
12. Left click the BACKUP box, when backup complete message appears remove the memory stick.
13. Left click the CLOSE box.